



TRANSICOLD

OPERATION AND SERVICE MANUAL

**DIRECT DRIVE
REFRIGERATION UNIT**

XARIOS 150 / 200



Carrier

A United Technologies Company

Carrier Transicold Division, Carrier Corporation, P.O. Box 4805, Syracuse, N.Y. 13221 U. S. A.

Carrier Transicold E.T.O. Boite Postale Nr. 16 Franqueville - Saint-Pierre 76520 Boos, FRANCE

© Carrier Corporation 2001 • Printed in France 62-61113-00 06/01

XARIOS 150 / 200

OPERATION AND SERVICE MANUAL

This operation and service manual has been prepared for the Carrier Transicold technicians who have to do maintenance services on the XARIOS 150 / 200 refrigeration unit.

This manual contains operating data, electrical data, safety and service instructions which have to be done on this unit.

This refrigeration unit has been designed with the safety of the technician in mind. During normal operation, all moving parts are fully enclosed to help prevent injury. During all pre-trip inspections, daily inspections and problem troubleshooting, you may be exposed to moving parts : **we advise you to take all required precautions, general and individual (glasses, gloves wearing...) during all maintenance services on this unit.**

TAKE EVERY SAFETY MEASURE WHEN ACCESSING THE UNIT : use standard ladders, running board with railing, safety belt etc...

At Carrier Transicold, we are continually working to improve the products that we build for our customers. As a result, specifications may change without notice.

TABLE OF CONTENTS

	Page
Section 1	
DESCRIPTION	1-1
1.1 Introduction	1-1
1.2 Compressor reference data	1-5
1.3 Refrigeration system data	1-5
1.4 Electrical data	1-5
1.5 Torque values	1-6
1.6 Safety devices	1-6
1.7 Cab command	1-7
1.7.1 Introduction	1-7
1.7.2 Keypad	1-7
1.7.3 Digital display	1-8
1.7.4 Set-point	1-8
1.7.5 Configuration	1-8
1.7.6 Defrost cycle	1-9
1.7.7 Alarm display	1-10
1.7.8 Other data	1-11
1.7.9 Changing display brightness	1-11
1.8 Compressor pressure regulating valve	1-12
1.9 Hot gas solenoid (two-way)	1-12
1.10 Condenser closing solenoid (two-way) - Option	1-12
1.11 Refrigerant circuit during cooling (see Figure 1-11)	1-12
1.12 Refrigerant circuit during heat and defrost (see Figure 1-12)	1-12
Section 2	
OPERATION	2-1
2.1 Control and starting up	2-1
2.1.1 On road	2-1
2.1.2 On standby (road / standby version)	2-1
Section 3	
SERVICE	3-1
3.1 Unit maintenance	3-1
3.1.1 Unit maintenance schedules	3-1
3.1.2 Description of maintenance operations	3-1
3.2 Belt maintenance and adjustment	3-2
3.2.1 Belt tension gauge (road compressor)	3-2
3.3 Removing the refrigerant charge	3-2

3.4	Refrigerant leak checking	3-2
3.5	Evacuation and dehydration	3-3
3.5.1	General	3-3
3.5.2	Preparation	3-3
3.5.3	Evacuation and dehydration procedure	3-3
3.6	Charging the refrigeration system	3-4
3.6.1	Installing a complete charge	3-4
3.6.2	Adding a partial charge	3-4
3.6.3	Checking the refrigerant charge	3-5
3.7	Replacing the compressor	3-5
3.8	Checking and replacing filter-drier	3-5
3.9	Checking and replacing high pressure cutout switch	3-5
3.9.1	Replacing high pressure cutout switch	3-5
3.9.2	Checking high pressure cutout switch	3-5
3.10	Checking and replacing condenser fan motor brushes	3-6
3.11	Evaporator coil-cleaning	3-6
3.12	Condenser coil-cleaning	3-6
3.13	Hot gas (two-way) solenoid and condenser closing solenoid (two-way)	3-7
3.13.1	Replacing solenoid coil	3-7
3.13.2	Replacing solenoid valve internal parts	3-7
3.14	Adjusting the road compressor pressure regulating valve (cpr)	3-7
3.15	Thermostatic expansion valve	3-8
3.16	Microprocessor	3-8

Section 4

TROUBLESHOOTING	4-1	
4.1	Refrigeration	4-1
4.1.1	Unit will not cool	4-1
4.1.2	Unit runs but has insufficient cooling	4-1
4.1.3	Unit operates long or continuously in cooling	4-1
4.1.4	Unit will not heat or heating insufficient	4-1
4.1.5	Defrost malfunction	4-1
4.1.6	Abnormal pressure	4-2
4.1.7	Abnormal noise	4-2
4.1.8	Cab command malfunction	4-2
4.1.9	No evaporator air flow or restricted air flow	4-2
4.1.10	Expansion valve malfunction	4-3
4.1.11	Malfunction hot gas (two-way) solenoid / expansion closure valve	4-3
4.2	Standby compressor malfunction	4-3

Section 5

ELECTRICAL SCHEMATIC WIRING DIAGRAMS	5-1
---------------------------------------------------	------------

LIST OF FIGURES

Figure 1-1	XARIOS 200	1-1
Figure 1-2	Unit top view	1-2
Figure 1-3	Evaporator top view	1-3
Figure 1-4	Evaporator rear view	1-3
Figure 1-5	Evaporator right view	1-3
Figure 1-6	Evaporator left view	1-3
Figure 1-7	Three phases Road/Stansby control box	1-4
Figure 1-8	Single phase Road/Stanby control box	1-4
Figure 1-9	Relay module	1-4
Figure 1-10	Cab Command	1-7
Figure 1-11	Cooling Cycle	1-13
Figure 1-12	Heating and defrost Cycle - under 17 bar	1-14
Figure 1-13	Heating and defrost Cycle - over 22 bar	1-15
Figure 2-1	Thermostat operating sequence Standby or road operation Set-point higher than -12°C ($+10^{\circ}\text{F}$)	2-2
Figure 2-2	Thermostat operating sequence Standby or road operation Set-point lower than -12°C ($+10^{\circ}\text{F}$)	2-3
Figure 3-3	Road compressor belt tension	3-2
Figure 3-4	Vacuum pump connection	3-4
Figure 3-5	Typical setup for testing high pressure switch 1 and HP2	3-5
Figure 3-6	Fan motor brushes	3-6
Figure 3-7	Hot gas (two-way) solenoid or Condenser closing solenoid (Two-way) ..	3-7
Figure 3-8	Compressor pressure regulating valve	3-7
Figure 3-9	Thermostatic expansion valve bulb and thermocouple	3-8
Figure 5-1	Electrical schematic diagram - ROAD - 12V/24V	5-2
Figure 5-2	Electrical schematic diagram - ROAD - 230/1/50Hz - 208-230/1/60Hz ..	5-3
Figure 5-3	Electrical schematic diagram -ROAD - 400/3/50Hz	5-4

LIST OF TABLES

Table 1-1	Model Chart	1-1
Table 1-2	Safety Devices - Microprocessor controller	1-6
Table 2-1	Management of condenser and evaporator fan and heat and defrost valve (from version 3.01)	2-4
Table 2-2	Management of condenser and evaporator fan and heat and defrost valve (until version 3.0)	2-4
Table 3-1	Maintenance schedules	3-1
Table 3-2	Pressure - Temperature R404A	3-9

SECTION 1

DESCRIPTION

1.1 INTRODUCTION

WARNING

Beware of unannounced starting of the fans and V-belts caused by the thermostat and the start/stop cycling of the unit.

This manual contains Operating Data, Electrical Data and Service Instructions for the truck refrigeration units listed in Table 1-1. Also Table 1-1 charts some significant differences between these models.

The XARIOS 150/200 model is a multi-piece unit designed for truck applications. Two types of drive are available :

- **Road operation**
 - driven by the engine of the vehicle when in operation over-the-road.
- **Road/Standby version**
 - driven by the engine of the vehicle when in operation over-the-road and by connecting the unit to the mains power on shut-down.

The model/serial nameplate is located inside of the unit on the frame as shown in Figure 1-1.

The standard control system is a microprocessor controller. Once the controller (remote Command within the cab of the truck) is set at the desired temperature, the unit will operate automatically to maintain the desired temperature within very close limits.

The control system automatically selects cooling and heating cycles as necessary to maintain the desired temperature.

The evaporator assembly consists of an evaporator coil, an expansion valve, one defrost thermostat (termination switches) and an electrical evaporator fan motor, one starting valve and on optional injection valve.

Model	R-404A		Road compressor	Standby compressor	Standby motor
	LB	KG			
XARIOS 150	2.7	1.2	UP 90	HA 090	220/240/1/50hz 208/230/1/60hz
XARIOS 200	4	1.4	TM 13	HA 090	115/1/60 hz 400/3/50hz




Figure 1-1 XARIOS 200

nameplate

XARIOS 150 / 200




Figure 1-2 Unit top view

- | | |
|-------------------------|-----------------------------------------|
| 1. Condenser fan | 9. Sight glass |
| 2. Accumulator | 10. Control box |
| 3. Standby check valve | 11. Microprocessor |
| 4. Road check valve | 12. Condenser |
| 5. Check valve (option) | 13. Condenser closing solenoid (option) |
| 6. Frame | 14. Condenser fan motor |
| 7. Compressor | 15. Transformer |
| 8. Filter-drier | 16. Safety switch |

EVAPORATOR




Figure 1-3
Evaporator
top view




Figure 1-4
Evaporator
rear view



Figure 1-5 Evaporator right view



Figure 1-6 Evaporator left view

1. Injection valve (option on Xarios 150)
2. Defrost termination thermostat
3. Evaporator fan blower
4. Heat exchanger
5. Defrost element
6. Evaporator coil
7. Frame
8. RAS sensor connector
9. Injection valve connector
10. Klixon connector
11. Fan connector
12. Liquid line
13. Standby suction line
14. Road suction line
15. Hot gas line
16. Left side cover
17. Bottom cover
18. Return air sensor
19. Right side cover
20. Starting valve
21. Expansion valve
22. Quick fitting for superheat adjustment

CONTROL BOX




Figure 1-7 Three phases Road/Standby control box




Figure 1-8 Single phase Road/Standby control box




Figure 1-9 Relay module

1. Standby contactor
2. Primary transformer fuse
3. Main standby fuses
4. Overload relay
5. Permanent capacitor

6. Filter capacitor
7. Microprocessor board
8. Standby fuse
9. Road main fuse
10. Diode bridge

1.2 COMPRESSOR REFERENCE DATA

Model	TM 13	HA090	UP 90
Displacement	131 cc (7.99 in ³)	12.7 cc (0.77 in ³)	92 cc (5.61 in ³)
No. Cylinders	6	-	10
Weight	6.7 kg	10.3 kg	6.2 kg
Oil Charge	200 cm ³	355 cm ³	180 cm ³
Approved oil	CARRIER POE #46-6002-02		

1.3 REFRIGERATION SYSTEM DATA

a. Defrost Timer

Automatic triggering or at present intervals :

0, auto, 1h, 2h, 3h, 4h, 5h, 6h

b. Defrost Thermostat

Opens at: 9° ± 3°C (48° ± 5°F)

Closes at: 3° ± 3°C (37° ± 5°F)

c. HP R404A Safety Pressure switch (HP1)

Cutout at : 32 bars (465 ± 10 psig)

Cut-in at : 25 bars (360 ± 10 psig)

d. HP R404A Control Pressure switch (HP2)

Cutout at : 17 bars (245 ± 10 psig)

Cut-in at : 22 bars (320 ± 10 psig)

e. Refrigerant charge

Refer to Table 1-1.

f. Compressor Pressure Regulating Valve (CPR)

in heating or defrost mode

MODEL	CPR Setting
	kg/cm ²
XARIOS 150	2.2 (2400 rpm)
XARIOS 200	1.4 (2400 rpm)

g. Thermostatic expansion valve superheat

Type :

XARIOS 150 : TEN 2 / Orifice n°1 / MOP 75 psi

XARIOS 200 : TEN 2 / Orifice n°2 / MOP 75 psi

Set for a box temperature of -20°C (0°F)

4°C (7 ± 1°F) during commissioning

h. R404A low pressure switch

Cutout at : -0.2 bar (-2.9 psig ± 3 psi)

Cut-in at : 1 bar (14.5 psig ± 3 psi)

i. Quench valve (option on Xarios 150)

Opens at: 127°C (260°F)

Closes at: 105°C (212°F)

1.4 ELECTRICAL DATA

a. Evaporator fan motors

Bearing lubrication : Factory lubricated

Horse power : 0.1 kw

Operating amps : 7 to 9 Amps

Speed : 2 200 rpm (rated)

Voltage : 12 vdc

b. Standby speed

- 2 900 rpm - 50 hz

- 3 480 rpm - 60 hz

c. Overview motor ratings

Voltage	Frequency	Phase	kW	HP	Standby motor rating		
					Constructor data		Unit overload setting
					MRA	LRA	
115 V	60 Hz	1	0.85	1.14	12.5 A	44.8 A	6.3 A
220/240 V	50 Hz	1	0.85	1.14	6.3 A	18.3 A	
208/230 V	60 Hz	1	0.85	1.14	7 A	23 A	
400 V	50 Hz	3	0.85	1.14	not available	6.47	1.5 A

MRA : Maximum Rotor Amps

LRA : Locked Rotor Amps

1.5 TORQUE VALUES

Assembly	kg-m	ft-lb
Standby compressor platform	5.5	40
Evaporator Fan Motor	1.8	13
Condenser - frame	1.0	7
Condenser Fan Blade	2.5	18
Mounting bolts	6 to 8	44 to 60

1.6 SAFETY DEVICES

System components are protected from damage caused by unsafe operating conditions by automatically shutting down the unit when such conditions occur. This is accomplished by the safety devices listed in Table 1-2.

Table 1-2 Safety Devices - Microprocessor controller			
Unsafe Conditions	Safety Device	Automatic restart with fault cleared	Device setting
1. Excessive drop in pressure	Automatic reset of low pressure switch	YES	Cutout : -0.2 bar (R404A)
2. Excessive current draw on all microprocessor outputs	Electronic relay	YES	Self-protected opening
3. Excessive current draw control circuit	Fuse on electronic board	NO	Self-protected opening
4. Excessive current draw standby motor	Overload relay	YES	See electrical wiring diagram
5. Excessive current draw evaporator and condenser fan motors	Electronic relay	YES	Self-protected opening
6. Excessive compressor discharge pressure	Automatic reset of High pressure switch (HP)		Cutout : 32 bar (R404A)
7. Excessive current draw unit on standby	Fuse 2	NO	Opens at : 30 A (12 V)
8. Excessive current draw unit on road	Fuse 1	NO	Opens at : 30 A (12 V)
9. Connection error on primary transformer	Fuse 4	NO	Opens at : 4 A
10. Excessive temperature on standby motor winding	O.L.P. (overload protector)	YES	Self-protected opening
11. Clutch malfunction - road (excessive current draw)	Electronic relay	YES	Self-protected opening
12. Clutch malfunction - road (insufficient current draw)	Electronic relay	YES	Detection of min. threshold at 750 mA
13. Double power supply (road + standby)	Microprocessor		Display on Cab Command until one of the 2 power supplies has been disconnected.
14. Low battery voltage	Microprocessor	YES	Cutout/cut-in at 10 V

1.7 CAB COMMAND

From his seat, the driver can carry out all the control operations :

- shut-down,
- automatic start-up in road or standby mode,
- adjusting the set-point,
- defrost.

The driver can display the box temperature, and see whether the set-point is being maintained by checking the green indicator. The indicator lights up red in the event of a malfunction.

When the battery voltage is too low, a fail-safe system shuts down the unit. Unit restart is automatic and time-delayed if the voltage rises to the normal level (see Figure 1-10)



Figure 1-10 Cab Command

1.7.1 Introduction

The microprocessor controller card is located in an aluminium control box. The controller comprises the microprocessor, the program memory and the input/output circuits required to interface with the unit.

The cab command is mounted remote in the cab. The command comprises the green and red LED readouts, the keypad and keypad interface (see Figure 1-10).

WARNING

The controller card and cab command must never be repaired by the driver! (see section 3.16). In the event of a malfunction with any of their components please contact your nearest Carrier Transicold distributor so that they can be replaced.

The Carrier Transicold microprocessor controls the following functions :

- Maintains the box temperature at set-point by regulating through cooling, heat, offmode and automatic defrost cycles.

- Permanently displays the return air temperature and on request the set-point temperature.

- Digital display and selection of data.

For further details on digital message display, see section 1.7.7.

1.7.2 Keypad

The keypad comprises six keys enabling the operator to activate various functions, display operating data and to modify operating parameters.

Display

	Readout
	Standby operation led
	Road operation led
	Unit operating data led <ul style="list-style-type: none"> ● Green : cycling (left-hand side) ● Red : malfunction (right-hand side)

Keys

	Manual defrost control key
	Unit start-up key
	Unit shut-down key in standby or road mode On road operation, the unit can be shut down with the ignition key.

Unit data and function modification

	The SET key, together with the + and - keys, enables display and modification of unit operating data. The display changes parameter each time the SET key is pressed.
	Decrement key for selected data
	Increment key for selected data





1.7.3 Digital display

The digital display comprises 4 alphanumeric characters. The default value displayed is the box temperature. The microprocessor enables selection of the display in degrees Celsius or Fahrenheit (see photo Road control box).

The display also includes settings for defrost operation (dF).

1.7.4 Set-point

Modification of the set-point temperature

	Display of the set-point temperature
	Decrease the set-point
	Increase the set-point
	Validates set-point temperature. Returns to display of the box temperature.


It is possible to increase or decrease the set-point by whole numbers until the required set-point is displayed. If display stays highlighted, this indicates the set-point displayed has not been validated.

The new setting for the set-point is validated by pressing the SET key.



1.7.5 Configuration



Access by the **configuration button** located on the rear of cab command.



Configuration button







	Press once on the configuration button.
--	-----------------------------------------


	TEMPERATURE UNIT Ut°C : celcius degree display Ut°F : farenheit degree display
	Press the + and - keys to change Ut°C or Ut°F.
	Press the SET key to validate.


	UNIT VOLTAGE PS12 : unit voltage 12 V PS24 : unit voltage 24 V
	Press the + and - keys to change PS12 or PS24.
	Press the SET key to validate.


	NUMBER OF EVAPORATOR FAN FAn1 : 1 fan FAn2 : 2 fans FAn3 : 3 fans
	Press the + and - keys to change FAn1, FAn2 or FAn3.
	Press the SET key to validate.


	FAN SPEED SPd- : 1st speed mini SPd : 2nd speed medium SPd≡ : 3rd speed maxi
	Press the + and - keys to change SPd-, SPd or SPd≡
	Press the SET key to validate.

	2 or 3 ET MODE 2 Et : cool, null 3 Et : cool, null, heat
	Press the + and - keys to change 2 Et or 3 Et.
	Note : Xarios 150/200 without condenser closing valve : 2 Et Xarios 150/200 with condenser closing valve : 3 Et
	Press the SET key to validate.

	<p>OPTIONAL ROAD HEATING KIT hrOF : option road heating kit not installed hrOn : option road heating kit installed</p>
	<p>Press the + and - keys to change hrOF or hrOn.</p> <p>Press the SET key to validate.</p>

	<p>OPTIONAL STANDBY HEATING KIT hSOF : option standby heating kit not installed hSOn : option standby heating kit installed</p>
	<p>Press the + and - keys to change hrOF or hrOn.</p> <p>Press the SET key to validate.</p>

	<p>DRAIN RESISTOR drOF : drain heater (option) not installed drOn : drain heater (option) installed</p>
	<p>Press the + and - keys to change drOF or drOn.</p> <p>Press the SET key to validate.</p>

	<p>DOOR SWITCH dOFF : door switch (option) not installed d On : door switch (option) installed</p>
	<p>Press the + and - keys to change dOFF or d On.</p> <p>Press the SET key to validate.</p>

IMPORTANT

If when settings are adjusted, no key is activated within 5 sec. the system reverts to displaying the box temperature. **All changes made are recorded with OFF/ON.**

1.7.6 Defrost cycle

Defrost is an independent cycle overriding cooling and heating functions, because it enables the evaporator to be defrosted when necessary. In defrost mode, the microprocessor displays “dF” on the cab command, which no longer displays the set-point.

DEFROST

Defrost is fully automatic but can be manually controlled if authorized by the defrost thermostat.

The defrost cycles are fully managed by the integrated microprocessor.

During the defrost phase, the evaporator fan shuts down. The condenser fan is controlled by the microprocessor.

The end of the cycle is controlled by a “Klixon” thermostat.

During the defrost phase, the readout of the cab command indicates “dF”.





a. Defrost

Defrost mode is activated by the microprocessor automatically or manually by the operator. The cycle stops when the defrost termination thermostat (DTT) is activated. The defrost interval timer is reset to zero when the defrost cycle is terminated, for whatever reason.

b. Defrost termination safety

If the defrost cycle does not terminate after 45 minutes, the cycle terminates automatically and displays alarm code A14.

c. Modification of defrost parameters

	Shut-down unit.
	Display parameters.
	Modify parameters.
	Validate modified settings. Return to display of box temperature.

0 : complete deletion of defrost.

0.5 to 0.9 : decreases time interval between 2 auto defrost cycles in relation to calculated time (coefficient 1).

AUT : automatic defrost optimized by the microprocessor according to the type of cargo transported (variable intervals).

1.1 to 1.5 : increases the time interval between 2 automatic defrost cycles in relation to calculated time (coefficient 1).

1 H, 2 H,... 6 H : Forced interval between each defrost expressed in hours.

IMPORTANT
If when settings are adjusted, no key is activated within 5 sec. the system reverts to displaying the box temperature. All changes made are recorded.

d. Minimum shut-down only on standby

The minimum shut-down for the standby motocompressor is 5 minutes.

After this minimum shut-down period, the unit restarts when the temperature goes out of the cycling range by 1.2 or 3 C (1.8. 3.6 or 5.4 F).

e. Battery voltage

If the battery voltage drops below

10 V for 12 volts unit


20 V for 24 volts unit

the unit shuts down and the cab command displays the message “bAt”.

1.7.7 Alarm display



Access to malfunction codes

Malfunction management

	Press SET for 5 seconds : enables access to malfunction codes.
-------------------------------------------------------------------------------------	----------------------------------------------------------------

MALFUNCTION CODES Red LED flashes	
R00	No malfunction. Unit in operation.
R01	Cut-out : low-pressure switch
R02	Cut-out : high-pressure safety switch.
R03	Cut-out : electric motor overload protection or overload relay
R04	Malfunction : road operation clutch control
R05	Malfunction : standby contactor control
R06	Malfunction : condenser fan control

R07	Malfunction : evaporator 1 fan control
R08	Malfunction : heating road 1 control (option)
R09	Malfunction : defrost valve control
R10	Malfunction : quench valve control
R11	Malfunction : heating valve control
R12	High temperature alarm
R13	Low temperature alarm
R14	Defrost alarm > 45 minutes
R15	Setpoint adjusted out of the range -29°C/+30°C
R16	Drain water resistor static control fault
R17	Thermal break down standby compressor
R18	Static control fault heating standby 1 control (option)
R19	Static control fault liquid valve 1
R20	LP standby pressure switch opened
R21	Open circuit detected standby compressor
R22	Open circuit detected condenser fan
R23	Open circuit detected heating road 1
R24	Open circuit detected defrost valve (HGS1)
R25	Open circuit detected liquid injection valve
R26	Open circuit detected hot gas valve (HGS2)
R27	Open circuit detected drain water resistor (DWR1)
R28	Open circuit detected heating standby 1

In case of several simultaneous malfunctions, use the keys   to list them.

NOTE	
Immediate display messages are displayed instead of temperature read-out as soon as the malfunction is detected, and remain displayed as long as malfunction persists.	
The unit does not run until the malfunction has disappeared or been corrected. Except for “ Twin power supply ” where the unit starts in Road mode.	

Immediate display in case of malfunction

EE	Malfunction : evaporator temperature probe
bAt	Low battery voltage low alarm (< 10 V)
---	Twin power supply (road and standby)
Err	Incorrect set-point setting
---	Setpoint lower than maximum setpoint but in the range -29°C/+30°C










GREEN LIGHT STATUS

SETPOINT	Green LED flashing 0.5 Hz	Set-point +5°C
	Green LED flashing 3 Hz	Set-point + differential hysteresis 1, 2, 3°
	Steady green LED	
	Steady green LED	Set-point - differential 1, 2, 3°
	Green LED flashing 3 Hz	
	Green LED flashing 0.5 Hz	Set-point - 5°C

The red alarm LED flashes at 3 Hz after 15' of high or low alarm (alarms AXX)

The red LED flashes at 0.5 Hz when the temperature goes back within the Set-point range differential (steady green LED) and the alarm becomes inactive (PXX).



1.7.8 Other data

	Press SET for 5 sec. : enables access to malfunction codes
	Display of codes for malfunctions
	Display of software versions
	Display of cab command software version
	Display of road hourmeter (Road led ON)
	Display of standby hourmeter (Standby led ON)
	Defrost interval (mn) calculated by the microprocessor between 2 defrosts
	Elapsed time (mn) since the last defrost
	Return to box temperature

IMPORTANT

If when settings are adjusted, no key is activated within 5 sec. the system reverts to displaying the box temperature. All changes made are recorded.

1.7.9 Changing display brightness

	Unit start-up
	Press during 5 seconds the + or - key to increase or decrease the display brightness.

1.8 COMPRESSOR PRESSURE REGULATING VALVE

- Road compressor

This CPR valve is installed on the suction line of the compressor to regulate the amount of suction pressure entering the compressor. The CPR valve is set to limit the maximum suction pressure. For CPR settings refer to section 1.4.

The suction pressure is controlled to avoid overloading engine during high box temperature operation. To adjust the CPR valve, refer to section 4.17

- Standby compressor

The suction pressure is controlled by the MOP expansion valve to avoid overloading engine of the standby compressor during high box temperature operation. Refer to section 1.3 for value.

1.9 HOT GAS SOLENOID (TWO-WAY)

The hot gas solenoid is normally closed (NC) and is only powered in defrost heat modes and 30 seconds before standby start-up.

If HP2 is closed, the condenser fan is ON.

If HP2 is opened, the condenser fan is OFF.

1.10 CONDENSER CLOSING SOLENOID (TWO-WAY) - OPTION

The condenser closing solenoid is normally open (NO). It is powered if the pressure switch for fan cycling is closed.

1.11 REFRIGERANT CIRCUIT DURING COOLING (SEE FIGURE 1-11)

When cooling, the unit operates as a vapor compression refrigeration system. The main components of the system are the reciprocating compressor, air-cooled condenser, thermostatic expansion valve, direct expansion evaporator, and hot gas solenoid (two-way).

The compressor raises the pressure and temperature of the refrigerant and forces it into the condenser tubes.

The condenser fan circulates surrounding air over the outside of the condenser tubes. Heat transfer is thus established from the refrigerant gas (inside the tubes) to the condenser air (flowing over the tubes). The condenser tubes have fins designed to improve the transfer of heat. This removal of heat causes the refrigerant to liquefy; liquid refrigerant flows from the condenser to the receiver.

The refrigerant then flows through a check valve (optional).

The refrigerant then flows through the filter-drier, where an absorbent keeps it dry and clean. The refrigerant then flows through a sight glass with moisture indication to the thermostatic expansion valve (with external pressure equalizer) which regulates the flow-rate of refrigerant towards the evaporator in order to obtain maximum use of the evaporator heat transfer surface.

The evaporator tubes have aluminium fins to increase heat transfer; therefore heat is removed from the air circulated through the evaporator. This cold air is circulated throughout the truck to maintain the cargo at the desired temperature.

The transfer of heat from the air to the low temperature liquid refrigerant causes the liquid to vaporize. The steam at low temperature and pressure enters the accumulator and is then drawn out by the compressor.

The refrigerant then enters the compressor pressure regulating valve (CPR) which regulates refrigerant pressure entering the compressor, where the cycle starts over.

The quench valve opens as required to maintain a maximum discharge temperature of 127°C (260 F).


1.12 REFRIGERANT CIRCUIT DURING HEAT AND DEFROST (SEE FIGURE 1-12)

When refrigerant vapor is compressed to a high pressure and temperature in a compressor, the mechanical energy necessary to operate the compressor is transferred to the gas it is being compressed. This energy is referred to as the "heat of compression" and is used as the source of heat during the heating cycle.

Case 1 : With condenser closing solenoid option. When the microprocessor activates heating or defrost, the hot gas (two-way) solenoid energizes, and (if HP2 is open) the condenser closing solenoid energizes, closing the port to the condenser and opening a port which allows heated refrigerant vapor to flow directly to the evaporator coil.

Case 2 : Without condenser closing solenoid option. When the microprocessor activates heating or defrost, the hot gas solenoid (two-way) energizes, opening a port which allows heated refrigerant vapor to flow directly to the evaporator coil.


The main difference between heating and defrosting is that, when in heating mode all the evaporator fans continue to run, blowing the air around the heated coils to heat the product. When defrosting, the evaporator fans stop, allowing the heated vapor to defrost any ice build-up there may be.



- High pressure vapor
- High pressure liquid
- Low pressure vapor
- Low pressure liquid


- | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> 1. Liquid injection valve 2. Thermostatic expansion valve 3. Heat exchanger (for Xarios 200 only) 4. Check valve (option) 5. Sight glass 6. Filter drier 7. Shut-off valve 8. Receiver 9. Condenser 10. Condenser closing valve - normally open (option) 11. Relief valve RV 12. Control pressure switch | <ul style="list-style-type: none"> 13. High pressure switch 14. Road discharge check valve 15. Standby discharge check valve 16. Standby compressor 17. Accumulator 18. Klixon (for liquid injection valve) 19. Road compressor 20. Low pressure switch 21. Starting valve 22. Hot gas valve (normally closed) 23. Defrost element 24. Evaporator |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Figure 1-11 Cooling Cycle



- | | |
|------------------------------------------------------|-----------------------------------------|
| 1. Liquid injection valve | 13. High pressure switch |
| 2. Thermostatic expansion valve | 14. Road discharge check valve |
| 3. Heat exchanger (for Xarios 200 only) | 15. Standby discharge check valve |
| 4. Check valve (option) | 16. Standby compressor |
| 5. Sight glass | 17. Accumulator |
| 6. Filter drier | 18. Klixon (for liquid injection valve) |
| 7. Shut-off valve | 19. Road compressor |
| 8. Receiver | 20. Low pressure switch |
| 9. Condenser | 21. Starting valve |
| 10. Condenser closing valve - normally open (option) | 22. Hot gas valve (normally closed) |
| 11. Relief valve RV | 23. Defrost element |
| 12. Control pressure switch | 24. Evaporator |

Figure 1-12 Heating and defrost Cycle - under 17 bar



- | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ol style="list-style-type: none"> 1. Liquid injection valve 2. Thermostatic expansion valve 3. Heat exchanger (for Xarios 200 only) 4. Check valve (option) 5. Sight glass 6. Filter drier 7. Shut-off valve 8. Receiver 9. Condenser 10. Condenser closing valve - normally open (option) 11. Relief valve RV 12. Control pressure switch | <ol style="list-style-type: none"> 13. High pressure switch 14. Road discharge check valve 15. Standby discharge check valve 16. Standby compressor 17. Accumulator 18. Klixon (for liquid injection valve) 19. Road compressor 20. Low pressure switch 21. Starting valve 22. Hot gas valve (normally closed) 23. Defrost element 24. Evaporator |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Figure 1-13 Heating and defrost Cycle - over 22 bar

SECTION 2

OPERATION

2.1 CONTROL AND STARTING UP

Evaporator motor : During the starting mode, the motor speed increases continuously from 0 to 2200 rpm in 30 seconds.



Start-up equalization : The hot gas valve is energized for few seconds.

2.1.1 On road

Check the belt tension of the compressor drive belts.

Start-up and control of box temperature

Start the vehicle engine

	<p>Press the ON key to start the unit (start-up is time-delayed for 40 seconds). The digital display of the cab command displays the box temperature.</p>
	<p>Check the temperature set-point is correct by pressing the SET key; the set-point temperature is highlighted on the digital display.</p>


Enter a new set-point if necessary (see temperature set-point adjustment).

In the event of difficulty on start-up, check that :

The control box fuses have not blown.

The temperature selected by the cab command has not been affected.

Unit shut-down

	<p>Turn off the ignition key or press the OFF key.</p>
-------------------------------------------------------------------------------------	--------------------------------------------------------

2.1.2 On standby (road / standby version)

VERY IMPORTANT

The unit must be shut-down to connect or disconnect the standby supply cable.

Before start-up, check :



- On the power network :

Check that the type of current corresponds to the characteristics of the unit (see section 1.8).

- On the power unit :


Connect the unit to the power network.

Start-up and box temperature control

	<p>Press the ON key to start the unit (start-up is time-delayed for 40 seconds). The digital display of the cab command displays the box temperature.</p>
	<p>Check the temperature set-point is correct by pressing the SET key; the set-point temperature is highlighted on the digital display.</p>

Enter a new set-point if necessary (see temperature set-point adjustment).

Unit shut-down

	<p>Press the OFF key.</p>
-------------------------------------------------------------------------------------	---------------------------

If you have difficulty in starting up, check:

The set-point temperature selected on the cab command has not been reached.

The control box fuses have not blown.

COOLING

There are two control ranges, Frozen and Perishable. The frozen range is active with set points at or below -12 C ($+10\text{ F}$) and the Perishable range is active at set points above -12 C ($+10\text{ F}$).

The controller automatically selects the mode necessary to maintain box temperature at set point.

HEATING

See section 1.12 for a description of the heating cycle.

The unit will only heat when the controller is set above -12 C ($+10\text{ F}$) as the heat relays are electronically locked out with set points at or below -12 C ($+10\text{ F}$).

The microprocessor automatically selects the mode necessary to maintain box temperature at set point. In pulldown the heating modes are as follows (Figure 2-1 and Figure 2-2) :





Figure 2-1 Thermostat operating sequence
Standby or road operation
Set-point higher than $-12\text{ }^{\circ}\text{C}$ ($+10\text{ }^{\circ}\text{F}$)



NOTE : The thermostat inhibits heat mode when it is set to a temperature lower than -12 C (+ 10 F).

Figure 2-2 Thermostat operating sequence
 Standby or road operation
 Set-point lower than -12 °C (+10 °F)

DEFROST

See section 1.12 for a description of heat and defrost cycles.

NOTE
When in Continuous Run, perishable range, the unit cycle between cool and heat to maintain box temperature at setpoint. In frozen range the unit will run in cool only. Continuous Run is normally used for perishable products that require constant air flow.

DEFROST ON STANDBY

Defrost on standby operates the same way as the defrost on road operation (see section 1.12).

**Table 2-1 Management of condenser and evaporator fan and heat and defrost valve
(from version 3.01)**

	EFM evaporator fan		CFM condenser fan	DWR drain water resistor	HGS2 heat valve	HGS1 defrost valve	HP2 pressure switch	Klixon defrost
Cool	ON		OFF	OFF	OFF	OFF	OPEN	XX
	ON		ON 3 mn minimum	OFF	OFF	OFF	CLOSED	XX
Cycling	OFF	ON if forced by config.	OFF	OFF	OFF	OFF	OPEN	XX
	OFF		OFF	OFF	OFF	OFF	CLOSED	XX
Heating if set-point = or > -12°C	ON		OFF	OFF	ON	ON	OPEN	XX
	ON		ON if HGS2 = OFF + 1mn	OFF	OFF 1mn mini	ON	CLOSED	XX
Defrost	OFF		OFF	ON	ON	ON	OPEN	CLOSED
	OFF		ON if HGS2 = OFF + 1mn	ON	OFF 1 mn mini	ON	CLOSED	CLOSED

**Table 2-2 Management of condenser and evaporator fan and heat and defrost valve
(until version 3.0)**

	EFM evaporator fan		CFM condenser fan	DWR drain water resistor	HGS2 heat valve	HGS1 defrost valve	HP2 pressure switch	Klixon defrost
Cool	ON		OFF	OFF	OFF	OFF	OPEN	XX
	ON		ON 3 mn minimum	OFF	OFF	OFF	CLOSED	XX
Cycling	OFF	ON if forced by config.	OFF	OFF	OFF	OFF	OPEN	XX
	OFF		OFF	OFF	OFF	OFF	CLOSED	XX
Heating if set-point = or > -12°C	ON		OFF	OFF	ON	ON	OPEN	OPEN
	OFF							CLOSED
	ON		ON if HGS2 = OFF + 1mn	OFF	OFF 1mn mini	ON	CLOSED	OPEN
	OFF							CLOSED
Defrost	OFF		OFF	ON	ON	ON	OPEN	CLOSED
	OFF		ON if HGS2 = OFF + 1mn	ON	OFF 1 mn mini	ON	CLOSED	CLOSED

Minimum "OFF" time (5 minutes): Once the motor has cycled off, it will remain off for the minimum "off time". This prevents the motor from rapid cycling due to changes in air temperature. Air temperature in the box change rapidly, but it takes time for the product temperature to change.

SECTION 3

SERVICE

CAUTION

Beware of V-belt and belt-driven components as the unit may start automatically. Before servicing unit, make sure the Run-Stop (ON/OFF) switch is in the OFF position. Also disconnect the negative battery cable.

NOTE

To avoid damage to the earth's ozone layer, use a refrigerant recovery system whenever removing refrigerant.

3.1 UNIT MAINTENANCE

3.1.1 Unit maintenance schedules

Regular servicing is required in order to optimize the service life and reliability of your unit. Service operations are to be carried out according to the following schedule.

Table 3-1 Maintenance schedules

Kilometers	5000	30 000	60 000	90 000	120 000	150 000	180 000	210 000
Miles	3000	18 000	36 000	54 000	72 000	90 000	108 000	126 000
Service A	■	■	■	■	■	■	■	■
Service B		■	■	■	■	■	■	■
Service C			■		■		■	
Service D					■			

Refrigerant : type R404A

Road compressor oil type: The road compressors are supplied with CARRIER POLYESTER (POE) oil. The presence of a sticker indicates that the oil-change has been correctly carried out in our CARRIER TRANSICOLD plant. Oils of PAG type are **strictly incompatible** with the operation of our units, **never use an oil other than that approved by CARRIER.**

Oil analysis :

On request we can analyze your compressor oil.

To do this, we send a small drum with a label on which you should indicate :

- the type of compressor,
- the lapse of time or mileage since the last oil change,
- the type of CARRIER equipment,
- the date of initial operation.

IMPORTANT

Before any operation requiring an intervention on the unit, check that :

- that the unit (cab command) is OFF.
- that it is impossible for the unit to automatically start up during maintenance.

3.1.2 Description of maintenance operations

Maintenance operations

Service A	<ul style="list-style-type: none"> ● Check the tension of the compressor belt(s) ● Check that the vehicle engine runs correctly at low speed and that the compressor kit is correctly tightened ● Check the tightness of bolts and screws and that the unit is correctly fastened onto the box
Service B	<ul style="list-style-type: none"> ● Clean the condenser and the evaporator ● Replace the road compressor belt(s) ● Replace the filter-drier ● Clean the TXV orifice filter ● Check the compressor oil level ● Check the operation of the cab command ● Check the defrost <ul style="list-style-type: none"> - Cut-in - Fan shut-down - Cut-out - Defrost water drain

Service C	<ul style="list-style-type: none"> ● Check the bearings of the belt tension pulleys and bearing of the mechanics kits. Change the spring if there is one. ● Change the shockmounts (if any) installed on the road compressor mounting kit. ● Check the operation of the evaporator and condenser fans. Change the motor brushes of condenser fan. ● Change the compressor oil. Only use Ester oil (POE) approved by CARRIER. See the technical information sheets for the recommended quantities and types of oil.
Service D	<ul style="list-style-type: none"> ● Change the removable relays and fuses in the control box.




Figure 3-3 Road compressor belt tension

Belt tension depends on each kit. In each kit installation instruction, we indicate the belt tension (given with belt tension gauge CLAVIS, type 1-30-300 Hz).

3.2 BELT MAINTENANCE AND ADJUSTMENT

CAUTION

Beware of V-belt and belt-driven components as the unit may start automatically.

3.2.1 Belt tension gauge (road compressor)

A belt tension gauge provides an accurate and easy method of adjusting belts to their proper tension. Properly adjusted belts give long lasting and efficient service. Too much tension shortens belt and bearing life, and too little tension causes slippage and excessive belt wear. It is also important to keep belts and sheaves free of any foreign material which may cause the belts to slip.

The Belt Tension gauge can be used to adjust all belts. The readings which we specify for Carrier Transicold units are applicable only for our belts and application, as the tension is dependent on the size of the belt and distance between sheaves. When using this gauge, it should be placed as close as possible to the midpoint between two sheaves.

When installing a new V-belt the tension should be somewhat higher than specified and readjusted after allowing the unit to run for some time.

3.3 REMOVING THE REFRIGERANT CHARGE

NOTE

Once the system is OPEN, it must be evacuated and dehydrated (see section 3.5.3).

Connect a refrigerant system to the unit to remove refrigerant charge. Refer to instruction provided by the manufacture of the refrigerant recovery system.

3.4 REFRIGERANT LEAK CHECKING

Once the recovery system is OPEN and repairs completed, leak check the unit by proceeding as follows:

- f. The recommended procedure for finding leaks in a system is with a halide torch or electronic leak detector. Testing joints with soapsuds is satisfactory only for locating large leaks.
- g. If system is without refrigerant, charge system with refrigerant to build up pressure between 2.1 to 3.5 kg/cm² (30 to 50 psig). Remove refrigerant cylinder and leak check all connections. **NOTE** Important: only the correct refrigerant cylinder be connected to pressurize the system. Any other gas or vapor will contaminate the system which will require additional purging and evacuation of the high side (discharge) of the system.

NOTE

Important : only the correct refrigerant cylinder be connected to pressurize the system. Any other gas or vapor will contaminate the system which will require additional purging and evacuation of the high side (discharge) of the system.

- h. Remove refrigerant using a refrigerant recovery system and repair any leaks. Evacuate and dehydrate the unit. (Refer to section 3.5) Charge unit with refrigerant. (Refer to section 3.6)

3.5 EVACUATION AND DEHYDRATION

3.5.1 General

Moisture is the deadly enemy of refrigerant systems. The presence of moisture in a refrigeration system can have many undesirable effects. The most common are copper plating, acid sludge formation, "freezing-up" of metering devices by free water, and formation of acids, resulting in metal corrosion.

3.5.2 Preparation

- a. Evacuate and dehydrate only after pressure leak test. (Refer to section 3.4).
- b. Essential tools to properly evacuate and dehydrate any system include a good vacuum pump (5cfm = 8m³H volume displacement, code 07-00176-01) and a good vacuum indicator such as a thermocouple vacuum gauge (vacuum indicator).

NOTE

Use of a compound gauge is not recommended because of its inherent inaccuracy.

- c. Keep the ambient temperature above 15.6 C (60 F) to speed evaporation of moisture. if ambient temperature is lower than 15.6 C (60 F), ice might form before moisture removal is complete. Heat lamps or alternate sources of heat may be used to raise system temperature.

3.5.3 Evacuation and dehydration procedure

- a. Remove refrigerant using a refrigerant recovery system.
- b. The recommended method to evacuate and dehydrate the system is to connect three evacuation hoses to the vacuum pump and refrigeration unit as shown in Figure 3-4 (do not use standard service hoses as they are not suited for evacuation purposes). Also, as shown, connect an evacuation manifold with special evacuation hoses to the vacuum pump, to the electronic vacuum gauge and to the refrigerant recovery system.
- c. Shut off the pump and check to see if the vacuum holds. This operation is to test the evacuation setup for leaks, repair if necessary.
- d. Open the vacuum pump and electronic vacuum gauge valves, if they are not already open. Start the vacuum pump. Evacuate unit until the electronic vacuum gauge indicates 2000 microns. Close the electronic vacuum gauge and vacuum pump valves. Shut off the vacuum pump. Wait a few minutes to be sure the vacuum holds.
- e. Break the vacuum with clean dry refrigerant. Use refrigerant that the unit calls for. Raise system pressure to approximately 2 psig.
- f. Remove refrigerant using a refrigerant recovery system.
- g. Repeat steps d. to f.
- h. Evacuate unit to 500 microns. Close off vacuum pump valve and stop pump. Wait five minutes to see if vacuum holds. This checks for residual moisture and/or leaks.
- i. With a vacuum still in the unit, the refrigerant charge may be drawn into the system from a refrigerant container on weight scales. The correct amount of refrigerant may be added by observing the scales (see section 3.6)

NOTE

Vacuum duration must be at least 8 hours.




Figure 3-4 Vacuum pump connection

3.6 CHARGING THE REFRIGERATION SYSTEM

3.6.1 Installing a complete charge

- a. Dry the refrigeration circuit and create a high vacuum (see section 3.5).
- b. Place refrigerant cylinder on scale and connect charging line from cylinder to manifold. Purge charging line at outlet valve. Purge charging line at inlet manifold.
- c. Note weight of refrigerant cylinder. Be sure that the unit is stopped during this operation.
- d. Open liquid valve on refrigerant cylinder. Open king valve half way and allow the liquid refrigerant to flow into the unit until the correct weight of refrigerant has been added as indicated by scales. (Correct charge will be found in section 1.2).

NOTE
It is possible that all liquid may not be pulled into the circuit, as outlined in step (d) above. In this case, vapor charge remaining refrigerant through the suction service valve (see section 3.6.2) with the unit in operation.

- e. When refrigerant cylinder weight (scale) indicates that the correct charge has been added, close the manifold valves.

3.6.2 Adding a partial charge

- a. Place refrigerant cylinder on scale and note weight. Backseat suction service valve and connect charging line between suction valve port and refrigerant cylinder.
- b. Run the unit in high speed cool and open suction service valve.
- c. If necessary partially block the condenser coil to raise the head pressure to 22 bars (R404A).

NOTE

When charging the refrigeration system with R404A, install a liquid charge.

- d. Open suction service valve. Close VAPOR valve on refrigerant cylinder, noting weight.
- e. Start unit and check for non-condensibles.

3.6.3 Checking the refrigerant charge

Start unit in cooling mode. Run approximately ten minutes. Partially block off air flow to condenser coil so discharge pressure rise to 22 bars (R404A).

The charge is correct if there are no bubbles at the coolant light level (10).

3.7 REPLACING THE COMPRESSOR

a. Evacuate the unit. Repeat the steps in section 3.3.

b. Installation

To install the compressor, reverse the procedure outlined when removing the compressor. Refer to section 1.5 for torque values.

Pump down the unit, see section 3.5 then charge system, see section 3.6.

3.8 CHECKING AND REPLACING FILTER-DRIER

Checking filter-drier

Check for any obstruction of the filter-drier by feeling the inlet and outlet connections of the liquid line on the filter cartridge. If the temperature of the discharge connection seems lower than that of the suction connection, replace the filter-drier.

Replacing the filter-drier

Remove the drier mounting clip, then replace the filter-drier.

3.9 CHECKING AND REPLACING HIGH PRESSURE CUTOUT SWITCH


3.9.1 Replacing high pressure cutout switch

- Remove defective switch.
- Install the new switch.

3.9.2 Checking high pressure cutout switch

CAUTION

Do not use a nitrogen cylinder without a pressure regulator. Cylinder pressure is approximately 165 kg/cm² (2350 psi). Do not use oxygen in or near a refrigerant system as an explosion may occur. (See Figure 3-5).



1. Cylinder valve and gauge
2. Pressure regulator
3. Nitrogen cylinder
4. Pressure gauge (0 to 400 psig = 0 to 28 bars)
5. Bleed-off valve
6. 1/4 inch connection

Figure 3-5 Typical setup for testing high pressure switch 1 and HP2

- a. Remove switch as outlined in section 3.9.1.
- b. Connect ohmmeter or continuity light across switch terminals. Ohmmeter will indicate resistance and continuity light will be lighted if switch is closed (HP1) or open (HP2) after relieving pressure.
- c. Connect switch to a cylinder of dry nitrogen (see Figure Figure 3-5)
- d. Set nitrogen pressure regulator higher than cut-out point on switch being tested. Pressure switch cut-in points are shown in sections 1.3.
- e. Close valve on cylinder and open bleed-off valve.

- f. Open cylinder valve. Slowly close bleed-off valve and increase pressure until the switch opens. If light is used, light will go out and if an ohmmeter is used, the meter will indicate open. Open pressure on gauge. Slowly open bleed-off valve (to decrease pressure) until switch closes (light will light or ohmmeter will move).

3.10 CHECKING AND REPLACING CONDENSER FAN MOTOR BRUSHES

The fan motor brushes should be checked periodically for cleanliness and wear to maintain proper operation of the fan motors.




Figure 3-6 Fan motor brushes

To check brushes proceed as follows :

- a. With unit off and battery disconnected, remove brush cap (item 1; 2 per motor). See Figure 3-6.
- b. Remove brushes (item 2; 2 per motor) and check the length of the brush. If the length is less than 1/4 inch (6 mm) the brushes should be replaced (after checking commutator).
- c. Blow out the brush holder with low pressure air to remove any carbon dust in the holder. This dust could prevent a good contact between the brushes and commutator.
- d. Remove the back cover of the motor and inspect the commutator. If the commutator is heavily grooved, polish it using fine sandpaper; do not use emery cloth. Wipe out any accumulation of greasy material using a clean rag dampened with solvent. Reassemble the motor; install new brushes and replace cap.

The evaporator fan motor is a brushless fan motor.

There is no maintenance on evaporator fan motor.

3.11 EVAPORATOR COIL-CLEANING

The use of recycled cardboard cartons is increasing. The recycled cardboard cartons create much more fiber dust during transport than "new" cartons. The fiber dust and particles are drawn into the evaporator where they lodge between the evaporator fins. If the coil is not cleaned on a regular basis, sometimes a often as after each trip, the accumulation can be great enough to restrict air flow, cause coil icing, repetitive defrosts and loss of unit capacity. Due to the "washing" action of normal defrost the fiber dust and particles may not be visible on the face of the coil but may accumulate deep within.

It is recommended to clean an the evaporator coil on a regular basis, not only to remove cardboard dust, but to remove any grease oil film which sometimes coats the fins and prevents water from draining into the drain pan.

Cardboard fiber particles after being wetted and dried several times can be very hard to remove. Therefore, several washings may be necessary.

- a. Spray coil with a mild detergent solution such as any good commercial-grade automatic dish washer detergent and let the solution stand for a few minutes. Reverse flush (opposite normal air flow) with clean water at mild pressure. A garden hose with spray nozzle is usually sufficient. Make sure drain lines are clean.
- b. Run unit until defrost mode be initiated to check for proper draining from drain pan.

3.12 CONDENSER COIL-CLEANING

Remove all foreign material from the condenser coil by reversing the normal air flow. (Air is pulled in through the front and discharges over the engine.) Compressed air or water may be used as a cleaning agent. It may be necessary to use warm water mixed with any good commercial dishwasher detergent. Rinse coil with fresh water if a detergent is used.

3.13 HOT GAS (TWO-WAY) SOLENOID AND CONDENSER CLOSING SOLENOID (TWO-WAY)

3.13.1 Replacing solenoid coil

It is not necessary to pump the unit down to replace the coil (see Figure 3-7).

- a. Remove coil snap cap, voltage plate and coil assembly. Disconnect leads and remove coil junction box if necessary.
- b. Verify coil type, voltage and frequency. This information appears on the coil voltage plate and the coil housing.
- c. Place new coil over enclosing tube and then install voltage plate and snap cap.

CAUTION

Do not damage or over tighten the enclosing tube assembly. Also make sure all parts are placed on the enclosing tube in proper sequence to avoid premature coil burn-out.




Figure 3-7 Hot gas (two-way) solenoid or Condenser closing solenoid (Two-way)

3.13.2 Replacing solenoid valve internal parts

If the hot gas solenoid is to be replaced, or if a service operation is scheduled on the internal components of the valve, the refrigerant must be evacuated.

- a. Remove and store the refrigerant charge in an evacuated container (see section 3.3).
- b. Remove coil snap cap, voltage cover and coil assembly. Remove the valve body head.
- c. Check for foreign material in valve body.

- d. Check for damaged plunger and O-ring. If O-ring is to be replaced, always put refrigerant oil on O-rings before installing.
- e. Tighten enclosing tube. If the valve has been removed from the circuit, check for eventual leaks.
- f. Install coil assembly, voltage cover and snap cap.
- g. Evacuate and dehydrate the circuit.
- h. Install a complete refrigerant charge.
- i. Start unit and check operation.

3.14 ADJUSTING THE ROAD COMPRESSOR PRESSURE REGULATING VALVE (CPR)

The CPR valve is not factory pre-set and need adjustment. It is necessary to adjust the valveduring commissioning, proceed with the following outline :

When adjusting the CPR valve, the unit must be running in the high speed heat or defrost. This will ensure a suction pressure above the proper CPR setting.




Figure 3-8 Compressor pressure regulating valve

To adjust the CPR valve, proceed as follows :

- a. Install a low-pressure.
- b. Remove cap (item 1) from CPR valve.
- c. With an 8 mm Allen wrench, loosen the jam nut (Figure 3-8, item 2.).
- d. Using the 8 mm Allen wrench, adjust the setting screw. To raise the suction pressure turn the setting screw (item 3.) clockwise; to lower the suction pressure, turn the setting screw counterclockwise. Refer to section 1.3 for CPR valve setting.
- e. When the setting has been adjusted, tighten the jam nut securely against the setting screw (item 3.). This will prevent any movement of the setting screw due to vibrations in the unit. Replace the cap.

3.15 THERMOSTATIC EXPANSION VALVE

MOP expansion valve characteristics :

- Rule : in order to avoid the standby motor overcharge, a MOP expansion valve (expansion valve with limited flow) is used.
- Operating : this kind of expansion valve can not open more than MOP setpoint. Any temperature increase of the sensor can not open more the expansion valve.

The thermal expansion valve is an automatic device which maintains constant superheat of the refrigerant gas leaving the evaporator regardless of suction pressure. The valve functions are: (a) automatic response of refrigerant flow to match the evaporator load and (b) prevention of liquid refrigerant entering the compressor. Unless the valve is defective, it requires adjustment, but maintenance must be done every year in order to clean the orifice filter.

a. Replacing expansion valve

1. Remove refrigerant charge.
2. Remove insulation from expansion valve bulb and then remove bulb from suction line.
3. Loosen inlet nut and unbrazed equalizer line and outlet line from expansion valve.
4. The thermal bulb is located below the center of the suction line. This area must be clean to ensure positive bulb contact. Strap thermal bulb to suction line and insulate both.
5. Braze the equalizer tubes to expansion valve.
6. Evacuate by placing vacuum pump on suction and discharge service valve.
7. Recharge unit.
8. Check superheat (see section 1.3).

b. Measuring superheat

NOTE
The expansion valve and bulb location are shown in Figure 3-9.

1. Remove insulation from expansion valve bulb and suction line.
2. Loosen one TXV bulb clamp and make sure area under clamp (above TXV bulb) is clean.
3. Place thermocouple above (parallel) TXV bulb and then secure loosened clamp making sure both bulbs are firmly secured to suction line as shown in Figure 3-9.




Figure 3-9 Thermostatic expansion valve bulb and thermocouple

4. Connect an accurate gauge to the 1/4" port on the suction service valve.
5. Run unit until stabilized at -20°C (box temperature).
6. From the temperature/pressure chart, determine the saturation temperature corresponding to the evaporator outlet pressure.
7. Note the temperature of the suction gas at the expansion valve bulb.
8. Subtract the saturation temperature determined in Step 7 from the average temperature measured in Step 6. The difference is the superheat of the suction gas. (see section 1.3.f)

3.16 MICROPROCESSOR

Although there is less danger of electrical static discharge ESD damage in the outdoor environment, where the processor is likely to be handled, proper board handling techniques should always be stressed. Boards should always be handled by their edges, in much the same way one would handle a photograph. This not only precludes the possibility of ESD damage, but also lowers the possibility of physical damage to the electronic components. Although the microprocessor boards are fairly rugged when assembled, they are more fragile when separated and should always be handled carefully.

When welding is required on the unit frame, or on the front area of the trailer, ALL wiring to the microprocessor MUST be disconnected. When welding is performed on other areas of the truck and van, the welder ground connection MUST be in close proximity to the area being welded. It is also a good practice to remove both battery cables before wedding on either the unit frame or the truck to prevent possible damage to other components such as the alternator and voltage regulator.

Table 3-2 Pressure - Temperature R404A	
Temperature (°C)	Vapor pressure (bar abs.)
-60	0.50
-58	0.57
-56	0.63
-54	0.70
-52	0.78
-50	0.86
-48	0.95
-46	1.04
-44	1.14
-42	1.25
-40	1.37
-38	1.50
-36	1.63
-34	1.78
-32	1.93
-30	2.11
-28	2.27
-26	2.48
-24	2.65
-22	2.85
-20	3.09
-18	3.32
-16	3.57
-14	3.83
-12	4.11
-10	4.40
-8	4.71
-6	5.03
-4	5.38
-2	5.73

Table 3-2 Pressure - Temperature R404A	
Temperature (°C)	Vapor pressure (bar abs.)
0	6.11
2	6.50
4	6.92
6	7.35
8	7.80
10	8.28
12	8.77
14	9.29
16	9.83
18	10.39
20	10.98
22	11.59
24	12.22
26	12.89
28	13.57
30	14.29
32	15.03
34	15.80
36	16.61
38	17.44
40	18.30
42	19.19
44	20.12
46	21.08
48	22.07
50	23.10
52	24.16
54	25.26
56	26.40
58	27.57
60	28.79

SECTION 4

TROUBLESHOOTING

CAUTION

Under no circumstances should anyone attempt to service the microprocessor (see section 3.16). Should a problem develop with the microprocessor, contact your nearest Carrier Transicold dealer for replacement.

INDICATION / TROUBLE	POSSIBLE CAUSES	REFERENCE SECTION
4.1 REFRIGERATION		
4.1.1 Unit will not cool		
Compressor malfunction	Compressor drive defective Compressor defective	3.7 3.7
Refrigeration system	Defrost cycle has not terminated Abnormal pressure Hot gas (two-way) solenoid malfunction	4.1.5 4.1.6 4.1.11
4.1.2 Unit runs but has insufficient cooling		
Compressor	Compressor valves defective	3.7
Refrigeration system	Abnormal pressure Expansion valve malfunction No or restricted evaporator airflow	4.1.6 4.1.10 4.1.9
4.1.3 Unit operates long or continuously in cooling		
Box	Hot Load Defective box insulation or air leak	Insufficient pull down time Correct
Refrigeration system	Abnormal pressure Temperature controller malfunction	4.1.6 Figure 2-1 & Figure 2-2
Compressor	Defective	3.7
4.1.4 Unit will not heat or heating insufficient		
Refrigeration	Abnormal pressure Temperature controller malfunction Hot gas (two-way) solenoid malfunction	4.1.6 Figure 2-1 & Figure 2-2 4.1.11
Compressor	Compressor drive defective Compressor defective	3.7 3.7
4.1.5 Defrost malfunction		
Automatic defrost will not initiate	Defrost thermostats (DTT) open or defective Hot gas valve Electronic card malfunction	Replace Check operation Check defrost parameters
Manual defrost will not initiate	Microprocessor defective Defrost thermostats (DTT) open or defective	Replace Replace
Defrost cycle initiates but does not defrost	Hot gas (two-way) solenoid malfunction	4.1.11
Frequent defrost	Wet load	Check defrost parameters
Does not terminate or cycles on defrost	Defrost thermostats (DTT) shorted closed	Replace

INDICATION / TROUBLE	POSSIBLE CAUSES	REFERENCE SECTION
4.1.6 Abnormal pressure		
4.1.6.1 Cooling		
High discharge pressure	Condenser coil dirty Non-condensibles or refrigerant over-charge	3.12 Replace
Low discharge pressure	Compressor valves(s) worn or broken Hot gas (two-way) solenoid malfunction	3.7 4.1.11
High suction pressure	Compressor valves(s) worn or broken Hot gas (two-way) solenoid malfunction	3.7 4.1.11
Low suction pressure	Suction service valve partially closed Filter-drier partially plugged Low refrigerant charge Expansion valve malfunction No evaporator air flow or restricted air flow Excessive frost on coil	Open 3.8 3.6 4.1.10 4.1.9 Check
Suction and discharge pressures tend to equalize when unit is operating	Compressor valves defective Hot gas (two-way) solenoid malfunction	3.7 4.1.11
4.1.6.2 Heating		
High discharge pressure	Overcharged system Condenser fan of HP2 pressure switch defective Non-condensibles in system Condenser fan defective	3.6.3 3.9.2 Check Check
Low discharge pressure	Compressor valve(s) worn or broken Hot Gas -two-way valve malfunction	3.7 4.1.11
Low suction pressure	Refrigerant shortage Compressor pressure regulating valve malfunction	3.6 3.14
4.1.7 Abnormal noise		
Compressor	Loose mounting bolts Worn bearings Worn or broken valves Liquid slugging Insufficient oil	Tighten 3.7 3.7 4.1.10 Check / 3.7
Condenser or evaporator fan	Loose shroud Bearings defective Bent shaft	Check Check Check
4.1.8 Cab command malfunction		
Cab Command non-operational	Sensor defective Microprocessor malfunction Microprocessor/Cab command cable	3.16 3.16 Change
4.1.9 No evaporator air flow or restricted air flow		
Evaporator coil blocked	Frost on coil or dirty Fan motor(s) malfunction	Check
No or partial evaporator air flow	Evaporator fan loose or defective Evaporator fan rotating backwards Evaporator air flow blocked in box Fan motor(s) malfunction	Check Check

INDICATION / TROUBLE	POSSIBLE CAUSES	REFERENCE SECTION
4.1.10 Expansion valve malfunction		
Low suction pressure with high superheat	Low refrigerant charge External equalizer line plugged Ice formation at valve seat Wax, oil or dirt plugging valve or orifice Broken capillary Power assembly failure or partial Loss of element/bulb charge Superheat setting too high	3.4 / 3.6 Clean 3.5 3.15 3.15 Replace Replace 3.15
Low superheat and liquids lugging in compressor	Superheat setting too low External equalizer line plugged Pin and seat of expansion valve eroded or held open by foreign material	3.15 Open 3.15
Fluctuating suction pressure	Improper bulb location or installation Low superheat setting	3.15 3.15
High superheat	Expansion valve setting	Adjust
4.1.11 Malfunction hot gas (two-way) solenoid / expansion closure valve		
Valve does not function properly	No power to valve Improper wiring or loose connections Valve improperly assembled Coil or coil sleeve improperly assembled Movement of plunger restricted due to: a. Corroded or worn parts b. Foreign material lodged in valve c. Bent or dented enclosing tube	Check Check 3.13 3.13 3.13
Valve shifts but refrigerant continues to flow	Foreign material lodged under seat Defective seat	3.13 3.13
4.2 STANDBY COMPRESSOR MALFUNCTION		
Standby compressor fails to start	Motor contactor defective Motor Overload open Improper power supply Malfunction displayed on Cab Command 5-minute timer on standby	Replace Check/replace motor Check
Standby compressor starts, then stops	Motor Overload open High amperage draw	Check/replace motor Check

SECTION 5

ELECTRICAL SCHEMATIC WIRING DIAGRAMS

This section contains Electrical Schematic Wiring Diagrams covering the Models listed in Table 1-1. The following general safety notices supplement the specific warnings and cautions appearing elsewhere in this manual. They are recommended precautions that must be understood and applied during operation and maintenance of the equipment covered herein.

Model	Drawing #
ROAD - 12V/24V	62-60920
ROAD - 230/1/50Hz - 208-230/1/60Hz	62-60921
ROAD - 400/3/50Hz	62-60922

WARNING

Beware of unannounced starting of the fans and V-belts caused by the thermostat and the start/stop cycling of the unit.

CAUTION

**Under no circumstances should anyone attempt to repair the Logic or Display Boards !
Should a problem develop with these components, contact your nearest Carrier Transicold dealer for replacement.**

CAUTION


Observe proper polarity when installing battery, negative terminal must be grounded. Reverse polarity will destroy the rectifier diodes in alternator. As a precautionary measure, disconnect positive battery terminal when charging battery in unit. Connecting charger in reverse will destroy the rectifier diodes in alternator.

CAUTION

Under no circumstances should a technician electrically probe the processor at any point, other than the connector terminals where the harness attaches. Microprocessor components operate at different voltage levels and at extremely low current levels. Improper use of voltmeters, jumper wires, continuity testers, etc. could permanently damage the processor.

CAUTION

Most electronic components are susceptible to damage caused by electrical static discharge (ESD). In certain case, the human body can have enough static electricity to cause resultant damage to the components by touch. This is especially true of the integrated circuits found on the truck/trailer microprocessor.



5-2

Figure 5-1 - Electrical schematic diagram - ROAD - 12V/24V




Figure 5-3 - Electrical schematic diagram -ROAD - 400/3/50Hz