





Note (1): LIS, LIV and HT1,HT2 only for MAX units.  
 Note (2): EF3 will not be connected for V400 units.  
 Note (3): PS5 only for HEAT OPTION.

THE PC BOARD 2 IS LINKED WITH THE PC BOARD 1 INTERNALLY.  
 F20: IN ELECTRIC BOX, NEAR CONTACTOR&OVERLOAD  
 F21: NEAR BATTERY IN TRUCK  
 (\*)F2,F3,F4,F5,F6,F7,F9,F11: IN ELECTRIC PC BOARD

Capacitor	Resistor	Power	F20	F21	F2	F3	F4	F5	F6	F7	F9	F11
C1	R1	12A	4A	40A	15A	15A	15A	20A	10A	15A	15A	10A
68000µF 40V	2K2 1W	24V	10A	10A	10A	10A	10A	10A	7.5A	10A	10A	7.5A

